

Ανάπτυξη εγχειριδίου χρήσης της πειραματικής υποδομής NITOS

Σίμος Ιορδανίδης

Πανεπιστήμιο Θεσσαλίας
Τμήμα Μηχανικών Η/Υ Τηλεπικοινωνιών και
Δικτύων



University
of Thessaly



Στόχος

- Ο χρήστης της πειραματικής υποδομής του NITOS να μπορεί μέσω απλών βημάτων να μάθει πως να χρησιμοποιεί αυτήν και βασικές τεχνολογίες (**WiFi-WiMax-Openflow**)

Πώς υλοποιήθηκε ;

- Χρήση δυο εργαλείων:
 - Sphinx
 - Github





- Το Sphinx είναι ένα εργαλείο που μας επιτρέπει εύκολα και έξυπνα να κάνουμε documentation
- Λειτουργεί με απλό κώδικα σε text files
- Μεταφράζει το σύνολο των text files σε διάφορα formats(HTML,LaTex,PDF)

Πλεονεκτήματα

- Απλό στην εκμάθηση και χρήση.
- Δεν χρειάζεται να ασχοληθούμε εξ'ολοκλήρου με HTML/CSS αφού δημιουργούνται αυτόματα.
- Παρέχει πολλά HTML Themes.
 - Στο συγκεκριμένο εγχειρίδιο έγινε χρήση του default theme.

Παράδειγμα

.. test_nit documentation master file, created by
sphinx-quickstart on Sun Apr 6 12:53:31 2014.
You can adapt this file completely to your liking, but it should at least
contain the root `toctree` directive.

.. image:: _static/header-bg.png
:width: 30%
:height: 100px

.. image:: _static/NITlab_logo_layers.png
:width: 30%
:height: 100px

.. image:: _static/header-bg.png
:width: 30%
:height: 100px

NITlab documentation

First Steps on using NITOS

```
.. toctree::  
    :maxdepth: 2
```

```
account_create  
get_reserve  
connectNITOS  
loadOMF  
runOMF  
control_Nodes_Status  
save_OMFimage  
video_tutorials
```

OMF Example

```
.. toctree::  
    :maxdepth: 2
```

```
omf_example
```

Using Wifi

```
.. toctree::  
   :maxdepth: 2
```

wireless_example

Using WiMax

```
.. toctree::  
   :maxdepth: 2
```


wiMax

Using Openflow

```
.. toctree::  
   :maxdepth: 2
```

Openflow

- Χρησιμοποιώντας την εντολή **\$make html** στο τερματικό μας....έχουμε έτοιμο το html αρχείο.



The screenshot shows a Mozilla Firefox browser window with the title "NITlab documentation — Nitlab 1.0 documentation - Mozilla Firefox". The address bar shows "file:///home/simos/Eidiko/build/html/index.html". The main content area displays the "NITlab documentation" page. The header features the NIT LAB logo with the text "NIT LAB" and "NETWORK IMPLEMENTATION TESTBED LABORATORY". Below the header, the page title is "NITlab documentation". A sidebar on the left contains a "Table Of Contents" section with links to "Nitlab documentation", "First Steps on using NITOS", "OMF Example", "Using Wifi", "Using WiMax", and "Using Openflow". Other sidebar links include "Next topic", "Creating a User Account", "This Page", "Show Source", "Quick search", and a search bar. The main content area includes sections for "First Steps on using NITOS" (with a list of 10 items), "OMF Example" (with a list of 5 items), and "Using Wifi". The status bar at the bottom of the browser shows "gr" and "Simos" along with other system icons.

GitHub

- Social repository για projects ανοιχτού κώδικα που βασίζονται πάνω στο Git version control system.
- Εύκολη διαμοίραση κώδικα και συνεργασία σε projects.
- Χρησιμοποιήθηκε για versioning στο documentation.

NITlab documentation — N... Commits · syiordan/Eidiko

GitHub, Inc. (US) https://github.com/syiordan/Eidiko/commits/master

This repository Search Explore Gist Blog Help syiordan + ▾ Fork

syiordan / Eidiko Unwatch 1 Star 0 Fork 0

branch: master

- Commits on Sep 16, 2014
 - almost_end_v2
syiordan authored 21 hours ago
 - almost_end
syiordan authored 21 hours ago
- Commits on Aug 26, 2014
 - +wiMax
syiordan authored 22 days ago
- Commits on Jun 24, 2014
 - Adding files for Intro-OMF-Wireless
syiordan authored on Jun 24

Waiting for collector.githubapp.com...

© 2014 GitHub, Inc. Terms Privacy Security Contact Status API Training Shop Blog About

Δομή Εγχειριδίου

- Χωρίζεται σε 5 τμήματα:
 - **First steps on using Nitos**
 - **OMF Example**
 - **Using WiFi**
 - **Using WiMax**
 - **Using Openflow**

First Steps on using Nitos

Documentation — Nitlab 1.0 documentation - Mozilla Firefox

NITlab documentation — N... Commits · syiordan/Eidiko +

file:///home/simos/Eidiko/build/html/index.html#first-steps-on-using-nitos

Next topic Creating a User Account This Page Show Source Quick search Go Enter search terms or a module, class or function name.

First Steps on using NITOS

- [Creating a User Account](#)
- [Getting a Slice and Reserving Resources](#)
- [Connecting to NITOS Server](#)
- [Loading an OMF-compatible image on your resource](#)
- [Using your slice to run OMF experiments](#)
- [Controlling the status of the nodes](#)
- [Saving an OMF image from the resources to the server](#)
- [Nitlab Video Tutorials](#)

- Στα συγκεκριμένα sections περιγράφεται αναλυτικά πως ο χρηστής μπορεί να μάθει βασικά στοιχεία για την χρήση του testbed όπως να :
- Δημιουργήσει λογαριασμό στο NitLab
- Δεσμέψει slice και nodes
- Συνδεθεί στον Server
- Φορτώνει OMF-images στους κόμβους και να τρεχει OMF πειράματα.

Creating a User Account — Nitlab 1.0 documentation - Mozilla Firefox

Creating a User Account — ... Commits · syiordan/Eidiko file:///home/simos/Eidiko/build/html/account_create.html

Nitlab 1.0 documentation » Creating a User Account

Previous topic NITlab documentation
Next topic Getting a Slice and Reserving Resources
This Page Show Source Quick search

Enter search terms or a module, class or function name.

Go

Nitlab 1.0 documentation »

The first step you need to do before you can use NITOS is to create your NITlab account. This process is simple. Underneath the login boxes, click the “**Create an account**” link. Fill in the required information. Once you click the “**Register**” button, a confirmation mail will come to you and when you confirm it, your request will be sent to the administrator for approval. When the administrator approves the creation of your account, you will receive a confirmation email.

Example:

1. Visit <http://nitlab.inf.uth.gr/NITlab/>
2. Click “Create an account”
3. **Name:** Simos Iordanidis
Username: syiordan
Password: 1234
Confirm Password: 1234
Email Address: syiordan@inf.uth.gr
Confirm email Adress: syiordan@inf.uth.gr
4. Click Register
5. Confirm the mail you’ve received from administrator. The administrator will approve the creation of your account.

You are ready! You are a member of NITOS. At this time, you may continue with the next topic.

previous | next | index

© Copyright 2014, Simos Iordanidis. Created using [Sphinx 1.1.3](#).

Getting a Slice and Reserving Resources — Nitlab 1.0 documentation - Mozilla Firefox

Getting a Slice and Reservin... Commits · syiordan/Eidiko file:///home/simos/Eidiko/build/html/get_reserve.html

Nitlab 1.0 documentation » Getting a Slice and Reserving Resources

Previous topic Creating a User Account
Next topic Connecting to NITOS Server
This Page Show Source Quick search


Enter search terms or a module, class or function name.

Go

Nitlab 1.0 documentation »

All access to NITOS resources occurs through the “slice” abstraction.

The NITlab Administrator is in charge of managing your slice. You will need to contact him directly and ask him/her to either create a new slice for you, or add your user account to an existing slice. Once your account has been associated to a slice, you will be able to view the **Reservation page** and the “**Your ssh-keys**” page, at the User Menu on the right of the page.



Getting a Slice and Reserving Resources — Nitlab 1.0 documentation - Mozilla Firefox

file:///home/simos/Eidiko/build/html/get_reserve.html

Current Slices: syiordan.

Outdoor testbed CERTH Indoor testbed

Red dots represent Grid Nodes
Yellow dots represent Orbit Nodes
Green dots represent USRP Nodes
Orange dots represent Diskless Nodes

Current Server Time: 2014-04-16 18:06:00

Click on a date to select the day you want to start the reservation.

April 2014						
Su	Mo	Tu	We	Th	Fr	Sa
			1	2	3	4
6	7	8	9	10	11	12
13	14	15	16	17	18	19
20	21	22	23	24	25	26
27	28	29	30			

Select Slice, Start Time and Duration

Slice: syiordan

Start Date: 2014-4-16 yyyy/mm/dd

Start Time: 00 hh 00 min

Duration: 0.5 hours

Check Available Nodes

Your Details
Your ssh-keys
NITOS Scheduler
NITOS Scheduler - My Reservations
OpenFlow settings

Hi syiordan,
Log out

WHO'S ONLINE
We have 6 guests a

network b
nodes pa
modules sup
experiments frar

Slice names typically coincide with your NITlab site's account username. For example if your username is "**syiordan**" then your slice's name will probably be "**syiordan**". In next topics we will assume that your slice is named **username**. You should replace this value with your slice's actual name whenever you encounter it.

Connecting to NITOS Server — Nitlab 1.0 documentation - Mozilla Firefox

file:///home/simos/Eidiko/build/html/connectNITOS.html

Next topic
Loading an OMF-compatible image on your resource
This Page
Show Source
Quick search
Enter search terms or a module, class or function name.
Go

keypair, or would like to create a new one specifically for NITOS, perform the following commands. We will assume that `~/.ssh/id_rsa` is the private key that you will use for NITOS authentication.

```
$ ssh-keygen -t rsa -f ~/.ssh/id_rsa
Generating public/private rsa key pair.
Enter passphrase (empty for no passphrase):
Enter same passphrase again:
```

NITLAB
NETWORK IMPLEMENTATION TESTBED LABORATORY

Home Testbed Hardware Testbed Tools Demos Projects News Repository Contact us COURSE

ssh-keys

Current Slices: syiordan.

Choose the slice of which, you wish to check your uploaded rsa-keys: syiordan

Select

User MENU
Your Details
Your ssh-keys
NITOS Scheduler - Reservations
NITOS Scheduler - My Reservations
OpenFlow settings

Hi syiordan,
Log out

WHO'S ONLINE

Connecting to NITOS Server — Nitlab 1.0 documentation - Mozilla Firefox

Connecting to NITOS Server... Commits · syiordan/Eidiko file:///home/simos/Eidiko/build/html/connectNITOS.html

Home Testbed Hardware Testbed Tools Demos Projects News Repository Contact us COURSE

ssh-keys

Current Slices: syiordan.

These keys are stored in our database for the slice **syiordan!**
Upload your own public RSA keys in order to achieve passwordless login to Console Server via ssh!

Slice name: syiordan
ssh-rsa AAAAB3NzaC1yc2EAAAQABAAQDLIFhQb5ha68Hr1Ui8CWP
V5p04ALIDNTCVYv7mveEUutJW2gJEh1PdbFzFMH4gyTVZl0mRVks0PB1Oc
ZOmtTK41+OJUWtQxYaKZe57mC1ooi83bj3lHqeF8JNYxwy8CMwhd1adoVt6
64U/rW93nz/wYsdGei2TTmzuhkrCwwrotzUF+i956gzpZCU0s316w1X9SL8
U9nEOeLphq9YAPBDOzjhUkEx/cPyE7dX7eiFa2COBZkzPhNJgGhCLvDD8uHm
+keb65xykpAbQroYA7j/mubTHQosmAakIUAPlZ4xNuT+4JQ8CPpSYIBUgTd
eAm60KUaflkwVd4chR63 simos@simos-Aspire-5739G

Delete key

New ssh rsa-key: No file selected.

Hi syiordan,

WHO'S ONLINE

We have 12 guests and one member

nodes server part experiment framework

Open a secure shell to "nitlab.inf.uth.gr" (NITOS server) using your slice name as username. You do not need a password if you have uploaded your rsa public key in the server. You can log into the server at anytime you want to. However, you can only access the nodes you booked through the Reservation page.

It's time to connect to NITOS Server! Perform the following command:

Loading an OMF-compatible image on your resource — Nitlab 1.0 documentation - Mozilla Firefox

>Loading an OMF-compatible image on your resource... Commits · syiordan/Eidiko file:///home/simos/Eidiko/build/html/loadOMF.html

Nitlab 1.0 documentation »

Previous topic Connecting to NITOS Server

Next topic Using your slice to run OMF experiments

This Page Show Source

Quick search

Enter search terms or a module, class or function name.

Loading an OMF-compatible image on your resource

Ubuntu distributions, stored at the NITOS server as binary .ndz files, can be loaded on the resources overwriting any existing data on the disks of these resources.

Beginners can load a "baseline" distribution on their resources and later modify it according to their needs. There are two types of nodes supporting hard drive images at NITOS, the older Orbit-like nodes (the 'yellow' nodes) and the newer Commell nodes (the 'grid' nodes). For Orbit-like nodes the user should load the "baseline_orbit.ndz" image. For the grid nodes, the user should use "baseline_grid.ndz".

At any time you can look at **MyReservations**, to see all of your scheduled reservations, or at **Node Status** to see the status of your reserved nodes as well as to turn them on/off.

You can then load a "baseline" image for nodes you have reserved using the omf load command. For example, to load the baseline_grid.ndz image to node 16 of NITOS, issue in a terminal where you are connected to the NITOS Server:

```
$ omf load -i baseline_grid.ndz -t omf.nitos.node016
```

You can load an image to many nodes simultaneously using a comma separated list, for example:

```
$ omf load -i baseline_grid.ndz -t omf.nitos.node016,omf.nitos.node017
```

Once the loading process of one of the 'baseline' images is successfully completed, you can ssh into these nodes as root with no password. In a terminal where you are connected to the NITOS console server, issue

```
$ ssh root@node016
```

You can configure the image as you wish, since you have root privileges. One modification that you have to make is edit the file `/etc/omf/resctrl-5.3/omf/resctrl.yaml` and change the `:slice` section by putting your username instead of the entry `default_slice`. Another modification that you have to make to ensure no other user has access to your resource during your reservation is to add a root password to the image (using the `passwd command`). Note that you only need to do these changes once for each of the two types of nodes, since you can then save your modified image, so that you can load your "own" image each of the subsequent times you use some resources. This process of saving images is described in the next section.

Using your slice to run OMF experiments — Nitlab 1.0 documentation - Mozilla Firefox

Using your slice to run OMF ... Commits · syiordan/Eidiko

Nitlab 1.0 documentation »

Previous topic Loading an OMF-compatible image on your resource

Next topic Controlling the status of the nodes

This Page Show Source

Quick search

Enter search terms or a module, class or function name.

Using your slice to run OMF experiments

There are two ways to use your slice in order to run OMF experiments during your reservation. The first way is to install the **OMF Experiment Controller** locally at your PC and configure it appropriately and the second way is to issue OMF commands when logged in the server giving your slice as an option. We strongly recommend the second option, since every necessary component is in place in our Server, so we describe just the second method below. Running OMF Experiment Controller from the server

You can run OMF experiments while logged in the NITOS console server with your account. All you have to do is use the `-slice username` option when running the `omf exec` command (replacing `username` with your actual `username`).

previous | next | index

Nitlab 1.0 documentation »

© Copyright 2014, Simos Iordanidis. Created using Sphinx 1.1.3.

Controlling the status of the nodes — Nitlab 1.0 documentation - Mozilla Firefox

Controlling the status of th... Commits · syiordan/Eidiko

Nitlab 1.0 documentation »

Previous topic Using your slice to run OMF experiments

Next topic Saving an OMF image from the resources to the server

This Page Show Source

Quick search

Enter search terms or a module, class or function name.

Controlling the status of the nodes

You can use the custom made command `t_reboot` for checking your reserved nodes:

`$ t_reboot who`

or for rebooting all of them:

`$ t_reboot all hd`

or for rebooting all of them in pxe mode:

`$ t_reboot all pxe`

previous | next | index

Nitlab 1.0 documentation »

© Copyright 2014, Simos Iordanidis. Created using Sphinx 1.1.3.

Saving an OMF image from the resources to the server — Nitlab 1.0 documentation - Mozilla Firefox

file:///home/simos/Eidiko/build/html/save_OMPImage.html

Nitlab 1.0 documentation »

Previous topic
Controlling the status of the nodes

Next topic
Nitlab Video Tutorials

This Page
Show Source

Quick search

Enter search terms or a module, class or function name.

Go

Saving an OMF image from the resources to the server

You can save your modified image, in order to maintain the changes you've made and be able to use it again issuing the `omf save` command. For example, issuing

\$ omf save -n omf.nitos.node005

will save the current image of node 5 to the server. The image is saved as an `.ndz` file in the directory `/var/lib/omf-images-5.4` of the NITOS server with a name containing the date and time of the '`omf save`' command. You can then load this image to your resources using the `omf load` command and the name of the image. You can also rename the image, so that its name is more meaningful to you.

previous | next | index

NITlab Video Tutorials — Nitlab 1.0 documentation - Mozilla Firefox

file:///home/simos/Eidiko/build/html/video_tutorials.html

Nitlab 1.0 documentation »

Previous topic
Saving an OMF image from the resources to the server

Next topic
Simple OMF Example

This Page
Show Source

Quick search

Enter search terms or a module, class or function name.

Go

NITlab Video Tutorials

Video1: How to register at NITOS testbed



© Copyright 2014, Simos Iordanidis. Created using Sphinx 1.1.3.

previous | next | index

OMF Example

NITlab documentation — Nitlab 1.0 documentation - Mozilla Firefox

file:///home/simos/Eidiko/build/html/index.html

Enter search terms or a module, class or function name.

• NITlab Video Tutorials

OMF Example

- Simple OMF Example
 - 1.Basics
 - 2.Prerequisites
 - 3. Developing the Experiment
 - 4. Running Experiment
 - 5.Accesing Results

en 4:49 PM Simos

file:///home/simos/Eidiko/build/html/index.html

Enter search terms or a module, class or function name.

• NITlab Video Tutorials

OMF Example

- Simple OMF Example
 - 1.Basics
 - 2.Prerequisites
 - 3. Developing the Experiment
 - 4. Running Experiment
 - 5.Accesing Results

- Στα συγκεκριμένα sections περιγράφεται αναλυτικά πως ο χρήστης μπορεί να εξοικειωθεί με το OMF με το να :
 - Αναπτύξει ένα απλό πείραμα.
 - Να τρέξει αυτό το πείραμα
 - Να έχει πρόσβαση στα αποτελέσματα του πειράματος.

Simple OMF Example — Nitlab 1.0 documentation - Mozilla Firefox

file:///home/simos/Eidiko/build/html/omf_example.html#basics

Simple OMF Example

1.Basics

This simple example introduces you to OMF6. It presents all the basic steps to develop, run, and access the result of an experiment with OMF 6.

Experiment Scenario

This simple experiment involves a single resource of type PC, which has an active network interface. In this experiment, we will instruct that resource to start an instance of the 'ping-oml2' application to probe another host on the network attached to that interface (e.g. another host on the Internet, the LAN, or the resource's itself).

This 'ping-oml2' application is a wrapper around the traditional ping application. It captures the ping outputs and sends them as measurement streams to an OML2 collection point (an OML2 server in this case), which then stores them in a database available to the experimenter.

2.Prerequisites

a) Accessing/Provisioning Resources

Accessing a Resource at NITOS

Firstly, you have to reserve a node at NITOS: [Getting a Slice and Reserving Resources](#)

Provisioning a Resource at NITOS

You can use the method described on [Loading an OMF-compatible image on your resource](#) for instruction on how to image resources at NITOS. Load on your resource a disk image that contains OMF6. For example load the image `baseline_grid_omf6_1_1.ndz`.

b) Installing the Experiment Controller

Enter search terms or a module, class or function name. Go

Simple OMF Example — Nitlab 1.0 documentation - Mozilla Firefox

file:///home/simos/Eidiko/build/html/omf_example.html#basics

b) Installing the Experiment Controller

The OMF Experiment Controller (EC) is the software that will interpret your Experiment Description (ED) and interact with the resources to execute it accordingly.

You can install your own EC on your machine, by following the instructions for users on [OMF 6 Installation Guide](#)

3 Developing the Experiment

To run an experiment with OMF, you first need to describe it into an Experiment Description (ED). An ED is a file/script that is supplied as an input to the Experiment Controller (EC). It contains a detailed description of the resources involved in an experiment and the sets of actions to perform in order to realize that experiment. An ED is written using the OMF Experiment Description Language (OEDL).

The ED for our experiment:

Note:

```
# 1. Define an OMF Application Definition for the ping-oml2 application
# The OMF entities are using this definition to know where to find the
# application, what are its configurable parameters, and what are the
# OML2 measurement points that it provides.
# This ping-oml2 application will be known by OMF entities as 'ping_oml2'
#
defApplication('ping_oml2') do | app |
  app.description = 'Simple Definition for the ping-oml2 application'
  # Define the path to the binary executable for this application
  app.binary_path = '/usr/bin/ping-oml2'
  # Define the configurable parameters for this application
  # For example if target is set to foo.com and count is set to 2, then the
  # application will be started with the command line:
  # /usr/bin/ping-oml2 -a foo.com -c 2
  app.defProperty('target', 'Address to ping', '', { :type => :string })
```

Simple OMF Example — Nitlab 1.0 documentation - Mozilla Firefox

Commits · syordan/Eidiko

file:///home/simos/Eidiko/build/html/omf_example.html#basics

```
# Here we define only one group (Sender), which has only one resource in it
#
defGroup('Sender', 'node016') do | g |
    # Associate the application ping_oml2 defined above to each resources
    # in this group
    g.addApplication("ping_oml2") do | app |
        # Configure the parameters for the ping_oml2 application
        app.setProperty('target', '8.8.8.8')
        app.setProperty('count', 3)
        # Request the ping_oml2 application to collect measurement samples
        # from the 'ping' measurement point (as defined above), and send them
        # to an OML2 collection point
        app.measure('ping', :samples => 1)
    end
end

# 3. Define the sequence of tasks to perform when the event
# "all resources are up and all applications are installed" is being triggered
#
onEvent(:ALL_UP_AND_INSTALLED) do | event |
    # Print some information message
    info "This is my first OMF experiment"
    # Start all the Applications associated to all the Groups
    allGroups.startApplications
    # Wait for 5 sec
    # Stop all the Applications associated to all the Groups
    after 15 do
        allGroups.stopApplications
    end
    # Tell the Experiment Controller to terminate the experiment now
    after 10 do
        Experiment.done
    end
end
```

Simple OMF Example — Nitlab 1.0 documentation - Mozilla Firefox

Commits · syordan/Eidiko

file:///home/simos/Eidiko/build/html/omf_example.html#basics

4. Running Experiment

a) How do you run it?

To run your experiment you have to:

- save its description in a file on your computer, thus either**
 - cut-and-paste the above ED listing into a new file named 'tutorial000.rb'
 - download the ED directly: [ED_script](#)
- open a terminal and navigate to the folder/directory where you saved that file**
- start the EC software and tell it to execute the experiment described in your ED file, using the command line:**

```
omf_ec -u xmpp://usr:pwd@my_xmpp.com exec -oml_uri tcp:srv:port tutorial000.rb
```

 - replace `xmpp://usr:pwd@srv` with the credentials for your user on the xmpp pubsub server that is used to communicate with the resources
 - replace `tcp:srv:port` with the hostname/IP and port of the OML2 server which will collect the experiment's measurement
- So for our example, xmpp server and OML server run at nitlab.inf.uth.gr. Then you would use the command:**

```
omf_ec -u xmpp://nitlab.inf.uth.gr exec -oml_uri tcp:nitlab.inf.uth.gr:3003 tutorial000.rb
```

If you would like to know more about the other options of the OMF EC software please run the commands:

```
omf_ec help
omf_ec help exec
```

b) What will happen next?

Simple OMF Example — Nitlab 1.0 documentation - Mozilla Firefox

Simple OMF Example — Nit... Commits · syiordan/Eidiko file:///home/simos/Eidiko/build/html/omf_example.html#basics

b) What will happen next?

Screen Output

When running the EC with the above command, you should see an output similar to this :

```

OMF Experiment Controller - Copyright (c) 2012-13 National ICT Australia Limited (NICTA)
{:type=>:xml, :authenticate=>nil}
21:27:18 INFO XMPP::Communicator: Connecting to 'nitlab.inf.uth.gr' ...
INFO OML4R Client 2.10.4 [OMSPv4; Ruby 1.9.3] Copyright 2009-2014, NICTA
INFO Collection URI is tcp://nitlab.inf.uth.gr:3003
21:27:20 INFO XMPP::Communicator: Connected
21:27:20 INFO Object: OMF Experiment Controller 6.1.1 - Start
21:27:20 INFO Object: Connected using {:proto=>:xmpp, :user=>simos-aspire-5739g-2891, :domain=>nitlab.inf.uth.gr}
21:27:20 INFO Object: Execute: /home/simos/Eidiko/tutorial000.rb
21:27:20 INFO Obj{:type=>:xml}: Properties: {}
21:27:20 INFO OmfEc::Experiment: Experiment: 2014-05-28T18:27:18.121Z starts
21:27:20 INFO OmfEc::Experiment: Configure 'node016' to join 'Sender'
21:27:20 INFO OmfEc::Experiment: Newly discovered resource >> xmpp://node016@nitlab.inf.uth.gr
21:27:20 INFO OmfEc::Experiment: Event triggered: ALL_NODES_UP, ALL_UP
21:27:20 INFO OmfEc::Experiment: Config xmpp://node016@nitlab.inf.uth.gr to join Sender
21:27:21 INFO OmfEc::Experiment: Newly discovered resource >> xmpp://4980cefe-0117-442f-b743-49e57614fbef@nitlab.inf.uth.gr
21:27:21 INFO OmfEc::Experiment: Event triggered: ALL_UP_AND_INSTALLED
21:27:21 INFO Object: This is my first OMF experiment-simos
21:27:21 INFO OmfEc: APP_EVENT STARTED from app ping_oml2_cxt_0 - msg: env -i /usr/bin/ping-oml2 8.8.8.8 -c 3 -oml-config tmp/4980cefe-0117-442f-b743-49e57614fbef-1401301641.xml
21:27:21 INFO OmfEc: APP_EVENT STDERR from app ping_oml2_cxt_0 - msg: INFO ping-oml2: V2.10.4
21:27:21 INFO OmfEc: APP_EVENT STDERR from app ping_oml2_cxt_0 - msg: INFO OML4R Client 2.10.4 [OMSPv4; Ruby 1.9.3] Copyright 2009-2014,
21:27:21 INFO OmfEc: APP_EVENT STDERR from app ping_oml2_cxt_0 - msg: INFO Collection URI is

```

Simple OMF Example — Nitlab 1.0 documentation - Mozilla Firefox

Simple OMF Example — Nit... Commits · syiordan/Eidiko file:///home/simos/Eidiko/build/html/omf_example.html#basics

```

21:27:21 INFO OmfEc::Experiment: Event triggered: 'ALL_UP_AND_INSTALLED'
21:27:21 INFO Object: This is my first OMF experiment-simos
21:27:21 INFO OmfEc: APP_EVENT STARTED from app ping_oml2_cxt_0 - msg: env -i /usr/bin/ping-oml2 8.8.8.8 -c 3 -oml-config tmp/4980cefe-0117-442f-b743-49e57614fbef-1401301641.xml
21:27:21 INFO OmfEc: APP_EVENT STDERR from app ping_oml2_cxt_0 - msg: INFO ping-oml2: V2.10.4
21:27:21 INFO OmfEc: APP_EVENT STDERR from app ping_oml2_cxt_0 - msg: INFO OML4R Client 2.10.4 [OMSPv4; Ruby 1.9.3] Copyright 2009-2014, NICTA
21:27:21 INFO OmfEc: APP_EVENT STDERR from app ping_oml2_cxt_0 - msg: INFO Collection URI is tcp://nitlab.inf.uth.gr:3003
21:27:24 INFO OmfEc: APP_EVENT STDOUT from app ping_oml2_cxt_0 - msg: 64 bytes from 8.8.8.8: icmp_req=1 ttl=45 time=58.6 ms
21:27:24 INFO OmfEc: APP_EVENT STDOUT from app ping_oml2_cxt_0 - msg: PING 8.8.8.8 (8.8.8.8) 56(84) bytes of data.
21:27:24 INFO OmfEc: APP_EVENT STDOUT from app ping_oml2_cxt_0 - msg: 64 bytes from 8.8.8.8: icmp_req=3 ttl=45 time=58.7 ms
21:27:24 INFO OmfEc: APP_EVENT STDOUT from app ping_oml2_cxt_0 - msg: 64 bytes from 8.8.8.8: icmp_req=2 ttl=45 time=58.6 ms
21:27:24 INFO OmfEc: APP_EVENT STDOUT from app ping_oml2_cxt_0 - msg:
21:27:24 INFO OmfEc: APP_EVENT STDOUT from app ping_oml2_cxt_0 - msg: — 8.8.8.8 ping statistics —
21:27:25 INFO OmfEc: APP_EVENT STDOUT from app ping_oml2_cxt_0 - msg: 3 packets transmitted, 3 received, 0% packet loss, time 2002ms
21:27:25 INFO OmfEc: APP_EVENT STDOUT from app ping_oml2_cxt_0 - msg: rtt min/avg/max/mdev = 58.657/58.676/58.712/0.199 ms
21:27:25 INFO OmfEc: APP_EVENT EXIT from app ping_oml2_cxt_0 - msg: 0
21:27:31 INFO OmfEc::Experiment: Experiment: 2014-05-28T18:27:18.121Z finished
21:27:31 INFO OmfEc::Experiment: Release applications and network interfaces
21:27:31 INFO OmfEc::Experiment: Exit in 15 seconds...
21:27:45 INFO OmfEc::Experiment: OMF Experiment Controller 6.1.1 - Exit.

```

5. Accessing Results

You can access your results by going to "tmp" file(i.e [syiordan@nitlab:/tmp\\$](syiordan@nitlab:/tmp$)) and type **ls**.

Using WiFi

NITlab documentation — Nitlab 1.0 documentation - Mozilla Firefox

en ☰ 5:05 PM Simos

NITlab documentation—N... Commits · syiordan/Eidiko

file:///home/simos/Eidiko/build/html/index.html

Using WiFi

- WiFi
 - 1.Basics
 - 2.Prerequisites
 - 3. Developing the Experiment
 - 4. Running Experiment
 - 5.Accesing Results

- Στα συγκεκριμένα sections περιγράφεται αναλυτικά στα αντίστοιχα βήματα με πρίν πως ο χρήστης μπορεί να εξοικειωθεί με την WiFi τεχνολογία με το να :
- Αναπτύξει ένα απλό wireless OMF πείραμα που γεννά κίνηση μεταξύ 2 κόμβων πάνω από ασύρματο κανάλι.
- Να τρέξει αυτό το πείραμα
- Να έχει πρόσβαση στα αποτελέσματα του πειράματος.

Using WiMax



- Στα συγκεκριμένα sections περιγράφεται αναλυτικά στα πως ο χρήστης μπορεί να εξοικειωθεί με την WiMax τεχνολογία με το να :
 - Αποκτήσει εικόνα της WiMax Topology.
 - Μάθει να συνδέεται στον κατάλληλο Server και στο WiMax Network.
 - Μάθει να χειρίζεται παραμέτρους του Base Station.
 - Αναπτύξει ένα απλό WiMax OMF πείραμα που γεννά κίνηση μεταξύ 2 κόμβων.
 - Να τρέξει αυτό το πείραμα
 - Να έχει πρόσβαση στα αποτελέσματα του πειράματος.

WiMax — Nitlab 1.0 documentation - Mozilla Firefox

WiMax — Nitlab 1.0 docum... Commits - syiordan/Eidiko wifi nitos topology - Αναζήτηση file:///home/simos/Eidiko/build/html/wiMax.html#basics wifi nitos topology

WiMax

- 1. Basics
- 2. Prerequisites
 - Accessing/Provisioning Resources
- 3. Experimental Topology
- 4. Connecting to the WiMAX Network
- 5. Set up experimentation properties of the BS
 - Services for BS
 - Services for mobile clients
- 6. Developing the experiment
- 7. Running Experiment
- 8. Accessing Results

Previous topic WiFi This Page Show Source Quick search Go

Enter search terms or a module, class or function name.

1. Basics

Firstly, you will see how to connect and use WiMax. You'll also see how to develop and run a simple experiment where the WiMAX interface is setup and generate traffic between two nodes.

2. Prerequisites

Accessing/Provisioning Resources

Accessing a Resource at NITOS

Firstly, you have to reserve a node at NITOS: [Getting a Slice and Reserving Resources](#)

In order to use the WiMAX testbed resources offered by the NITOS facility, you will have to reserve the WiMAX base station and the nodes with WiMAX connectivity, offered by the testbed (**Icarus nodes 41-49**).

Reserving the base station will render rights to the experimenter to access the WiMAXrf services of the testbed, used to configure and setup the base station at the experimenter's will.

After your reservation has started, login to Server.

Warning: You have to connect to **Nitos Server2!**

You can use your NITlab account to access the Nitos Server2. Just open a secure shell, write **ssh slice_name@nitlab2.inf.uth.gr** (i.e syiordan@nitlab2.inf.uth.gr) and log into the server.

Provisioning a Resource at NITOS

You can use the method described on [Loading an OMF-compatible image on your resource](#) for instruction on how to image resources at NITOS. Load on your resource a disk image that is compatible for WiMax experimentation such as **fgre_2014.ndz**.

WiMax — Nitlab 1.0 documentation - Mozilla Firefox

WiMax — Nitlab 1.0 docum... Commits - syiordan/Eidiko wifi nitos topology - Αναζήτηση file:///home/simos/Eidiko/build/html/wiMax.html#basics wifi nitos topology

3. Experimental Topology

The topology that we are examining in this tutorial is a central Base Station unit, able to route requests from an internal WiMAX network to the internet.

- The Base Station is using the 192.168.55.1 IP address
- Multiple clients use the 192.168.55.0/24 subnet to communicate with the Base Station
- Packets routed through the Base Station are sent over the internet through a NAT translation

The diagram illustrates the experimental topology. At the top right is an 'Airspeed AirG-WL24G WiMAX Base Station' connected to the 'Internet'. Below it is a 'WIMAX Configuration Server' with an IP of 192.168.55.3 / 24. A dashed line labeled 'Control Network' connects the Configuration Server to a 'NITOS2 Server'. From the NITOS2 Server, a dashed line labeled 'WiMAX Network' connects to three 'ICARUS Node' devices. Each ICARUS Node is connected to a 'Teltonika UM6225 WIMAX USB Modem'. The IP address 192.168.55.1 / 24 is assigned to the connection between the Configuration Server and the Base Station. The IP address 192.168.55.0 / 24 is assigned to the connections between the Configuration Server and the three ICARUS Nodes.

However, the devices that we currently use do not allow us to interface directly the WiMAX device. If you send the following command

```
root@node044:~# ifconfig tel0
```

WiMax — Nitlab 1.0 documentation - Mozilla Firefox

WiMax — Nitlab 1.0 docum... Commits · syiordan/Eidiko wifi nitos topology - Avazήτ...

file:///home/simos/Eidiko/build/html/wiMax.html#basics

4. Connecting to the WiMAX Network

In order to connect to the Base Station, issue the following commands:

Note:

```
wget -http-user admin -http-password admin -qO - "http://192.168.0.1/cgi/cli?stopSs"  
wget -http-user admin -http-password admin -qO - "http://192.168.0.1/cgi/cli?addChannel frequency=2590000  
bandwidth=10"  
wget -http-user admin -http-password admin -qO - "http://192.168.0.1/cgi/cli?startSs"
```

The first one, instructs the dongle to disconnect from any network that it is attached on. The second command, instructs the dongle to use the WiMAX channel at 2590MHz with a 10MHz channel bandwidth. Finally, with the third command the dongle connects to the NITOS WiMAX network. You can verify that the dongle has connected by sending the following command:

Note: ping 192.168.55.3

If the host responds, you are connected to the Base Station. Host 192.168.55.3 is the server behind the Base Station, responsible for configuring it and routing the traffic coming from it.

5. Set up experimentation properties of the BS

Before user starts an experiment with WiMax he/she has to configure BS with the specific parameters he/she wants. There is a basic command available to get or set the required parameters to BS. This is the '**wget**' command.

As soon as the parameters set, the experimenter can submit a new Experiment Definition(ED) written in OMF Experiment Description Language submit it to OMF's EC.

WiMax services are separated in two categories. The first one to configure the BS and the other one to configure the mobile clients. A description of these services is available to user, through the command : '**wget -qO- "http://wimaxrf:5054 /wimaxrf"**

WiMax — Nitlab 1.0 documentation - Mozilla Firefox

WiMax — Nitlab 1.0 docum... Commits · syiordan/Eidiko wifi nitos topology - Avazήτ...

file:///home/simos/Eidiko/build/html/wiMax.html#basics

If the host responds, you are connected to the Base Station. Host 192.168.55.3 is the server behind the Base Station, responsible for configuring it and routing the traffic coming from it.

5. Set up experimentation properties of the BS

Before user starts an experiment with WiMax he/she has to configure BS with the specific parameters he/she wants. There is a basic command available to get or set the required parameters to BS. This is the '**wget**' command.

As soon as the parameters set, the experimenter can submit a new Experiment Definition(ED) written in OMF Experiment Description Language submit it to OMF's EC.

WiMax services are separated in two categories. The first one to configure the BS and the other one to configure the mobile clients. A description of these services is available to user, through the command : '**wget -qO- "http://wimaxrf:5054 /wimaxrf/"**'

Services for BS

bs/arq

Note: Set ARQ parameters

bs/harq

Note: Set HARQ parameters

bs/security

Note: Set SECURITY parameters

bs/wireless

WiMax — Nitlab 1.0 documentation - Mozilla Firefox

WiMax — Nitlab 1.0 docum... Commits · syiordan/Eidiko wifi nitos topology - Αναζήτηση + File:///home/simos/Eidiko/build/html/wiMax.html#basics wifi nitos topology

Since the BS is back to its default settings, you can start experimenting with the WiMAX testbed.

6. Developing the experiment

To run an experiment with OMF, you first need to describe it into an Experiment Description (ED). An ED is a file/script that is supplied as an input to the Experiment Controller (EC). It contains a detailed description of the resources involved in an experiment and the sets of actions to perform in order to realize that experiment. An ED is written using the OMF Experiment Description Language (OEDL).

The ED for our experiment:

Note:

```
defProperty('runtime',20,"Time in second for the experiment is to run")
defProperty('client','192.168.55.48',"IP address of iperf server")
defProperty('interval','1',"Interval of Iperf measurements")
defProperty('sender','omf.nitos.node043','ID of sender node')
defProperty('receiver','omf.nitos.node048','ID of sender node')

defGroup('Sender', property.sender) do | node |
  node.net.t0.channel = "2590000,10"
  node.addApplication("test:app:iperf-5.4") do | app |
    app.setProperty('client', property.client)
    app.setProperty('interval', property.interval)
    app.setProperty('time', property.runtime)
    app.setProperty('udp', true)
    app.measure('transfer', :samples =>1)
  end
end

defGroup('Receiver', property.receiver) do | node |
  node.net.t0.channel = "2590000,10"
  node.addApplication("test:app:iperf-5.4") do | app |
    app.setProperty('server', true)
```

WiMax — Nitlab 1.0 documentation - Mozilla Firefox

WiMax — Nitlab 1.0 docum... Commits · syiordan/Eidiko wifi nitos topology - Αναζήτηση + File:///home/simos/Eidiko/build/html/wiMax.html#basics wifi nitos topology

7. Running Experiment

You can run it from the testbed server with the following command:

omf exec experiment.rb -slice your_username

Screen Output

When running the EC with the above command, you should see an output similar to this :

```
INFO NodeHandler: OMF Experiment Controller 5.4 (git 3105a52)
INFO NodeHandler: Slice ID: ardadouk
INFO NodeHandler: Experiment ID: ardadouk-2014-09-15t17.13.25+03.00
INFO NodeHandler: Message authentication is disabled
INFO Experiment: load system:exp:stdlib
INFO property.resetDelay: resetDelay = 90 (Fixnum)
INFO property.resetTries: resetTries = 1 (Fixnum)
INFO Experiment: load system:exp:eventlib
INFO Experiment: load wimax_experiment.rb
INFO property.runtime: runtime = 20 (Fixnum)
INFO property.client: client = 192.168.55.47" (String)
INFO property.interval: interval = 1" (String)
INFO property.sender: sender = omf.nitos.node046" (String)
INFO property.receiver: receiver = omf.nitos.node047" (String)
INFO Topology: Loading topology 'omf.nitos.node046'.
INFO Topology: Loading topology 'omf.nitos.node047'.
INFO Experiment: Switching ON resources which are OFF
INFO ALL_UP_AND_INSTALLED: Event triggered. Starting the associated tasks.
INFO exp: Request from Experiment Script: Wait for 50s....
INFO exp: This is an iperf experiment using a teltonika modem
INFO exp: Request from Experiment Script: Wait for 20s....
```

WiMax — Nitlab 1.0 documentation - Mozilla Firefox

WiMax — Nitlab 1.0 docum... Comits · syiordan/Eidiko wifi nitos topology - Avazήτ... +

file:///home/simos/Eidiko/build/html/wiMax.html#basics wifi nitos topology

8.Accessing Results

You can access your results in /tmp file with sqlite3.

Type a command similar to this:

```
ardadouk@nitlab2:~# sqlite3 /tmp/ardadouk-2014-09-15t17.13.25+03.00.sq3
```

```
SQLite version 3.7.9 2011-11-01 00:52:41
Enter ".help" for instructions
Enter SQL statements terminated with a ";"
```

```
sqlite> .dump
PRAGMA foreign_keys=OFF;
BEGIN TRANSACTION;
CREATE TABLE _senders (name TEXT PRIMARY KEY, id INTEGER UNIQUE);
INSERT INTO "_senders" VALUES('Sender',1);
CREATE TABLE _experiment_metadata (key TEXT PRIMARY KEY, value TEXT);
INSERT INTO "_experiment_metadata" VALUES('start_time','1410801183');
CREATE TABLE "iperf_transfer" (oml_sender_id INTEGER, oml_seq INTEGER, oml_ts_client REAL, oml_ts_server REAL,
"pid" INTEGER,
"connection_id" INTEGER, "begin_interval" REAL, "end_interval" REAL, "size" UNSIGNED BIGINT);
INSERT INTO "iperf_transfer" VALUES(1,1,1.12967199832201,-10720.634378,1305,4,0,0,1,0,132300);
INSERT INTO "iperf_transfer" VALUES(1,2,2.1184389963,461,-10719.670295,1305,4,1,0,2,0,130830);
INSERT INTO "iperf_transfer" VALUES(1,3,3.11740499734879,-10718.671336,1305,4,2,0,3,0,130830);
INSERT INTO "iperf_transfer" VALUES(1,4,4.11637899279594,-10717.672453,1305,4,3,0,4,0,130830);
INSERT INTO "iperf_transfer" VALUES(1,5,5.11532099545002,-10716.673515,1305,4,4,0,5,0,130830);
INSERT INTO "iperf_transfer" VALUES(1,6,6.11408699303865,-10715.674698,1305,4,5,0,6,0,130830);
INSERT INTO "iperf_transfer" VALUES(1,7,7.12316399812698,-10714.665473,1305,4,6,0,7,0,132300);
INSERT INTO "iperf_transfer" VALUES(1,8,8.12204399704933,-10713.666893,1305,4,7,0,8,0,130830);
INSERT INTO "iperf_transfer" VALUES(1,9,9.120899990201,-10712.668072,1305,4,8,0,9,0,130830);
INSERT INTO "iperf_transfer" VALUES(1,10,10.1199389994144,-10711.668989,1305,4,9,0,10,0,130830);
INSERT INTO "iperf_transfer" VALUES(1,11,11.1189429908991,-10710.670015,1305,4,10,0,11,0,130830);
INSERT INTO "iperf_transfer" VALUES(1,12,12.1177649945021,-10709.671234,1305,4,11,0,12,0,130830);
INSERT INTO "iperf_transfer" VALUES(1,13,13.1268289983273,-10708.662183,1305,4,12,0,13,0,132300);
INSERT INTO "iperf_transfer" VALUES(1,14,14.1257529854774,-10707.663297,1305,4,13,0,14,0,130830);
INSERT INTO "iperf_transfer" VALUES(1,15,15.1244789958,-10706.664623,1305,4,14,0,15,0,130830);
```

Using Openflow

Using Openflow

- Openflow
 - 1)OpenFlow testbed- Topology
 - 2)OpenFlow settings

Nitlab 1.0 documentation »

[next](#) | [index](#)

© Copyright 2014, Simos Iordanidis. Created using [Sphinx](#) 1.1.3.

- Στα συγκεκριμένα sections περιγράφεται αναλυτικά πως ο χρήστης μπορεί να εξοικειωθεί με την OpenFlow τεχνολογία με το να :
 - Αποκτήσει εικόνα για την OpenFlow τεχνολογία.
 - Αποκτήσει εικόνα για τα OpenFlow Settings.

Openflow — Nitlab 1.0 documentation - Mozilla Firefox

file:///home/simos/Eidiko/build/html/openflow.html#openflow-testbed-topology

Topology
2)OpenFlow settings

Previous topic
WiMax
This Page
Show Source
Quick search

Enter search terms or a module, class or function name. Go

NITOS facility provides remote access to OpenFlow switches, enabling the user to create an OpenFlow slice, related to an experiment slice that has already available. The OpenFlow slice is implemented by the FlowVisor, a Stanford's software tool that creates slices on the OpenFlow switches, enabling the parallel access to them by separate users. In a transparent way from the user perspective, the switches ports, which are used by the user's reserved nodes, are assigned to the user's OpenFlow slice. The whole process is orchestrated by the NITOS scheduler, configuring appropriately the FlowVisor at the beginning of a new reservation slot.

In summary, the remote user of the NITOS facility is able to reserve nodes for his slice (through the NITOS scheduler) and run an OpenFlow experiment with use of this slice. In particular, the testbed provides transparently an abstract OpenFlow switch for his slice, that conceptually is equivalent to a physical OpenFlow switch that includes only the ports of the nodes that he has reserved. The OpenFlow controller that defines the functionality of this abstract switch, should listen both on the host machine and the TCP port that are illustrated in the OpenFlow settings, in the User Menu on the right of the page (requires registration). The following figure illustrates the NITOS OpenFlow testbed topology, as well as the slicing mechanism.

Public IP

User

Internet

OpenFlow Protocol Experimentation Data

83.212.32.137

Your OpenFlow Controller could be either at the NITOS FlowVisor machine or at another publicly accessible machine of your choice.

FlowVisor

OpenFlow Switches

Openflow — Nitlab 1.0 documentation - Mozilla Firefox

file:///home/simos/Eidiko/build/html/openflow.html#openflow-testbed-topology

Topology
2)OpenFlow settings

2)OpenFlow settings

Current Slices: syiordan.

Along with the reservation of NITOS nodes, the related ports of the OpenFlow switches are also included in the corresponding experimentation slice. Please provide the IP address of the appropriate OpenFlow controller to perform an OpenFlow experiment with the use of this slice.

The current IP addresses of the OpenFlow controllers of each of your slices are depicted in the following table:

Slice	IP:	Port:
syiordan		

In case that one of the above IP addresses is 127.0.0.1, you can raise your OpenFlow controller at the NITOS FlowVisor server machine at 83.212.32.137. You are able to connect to the FlowVisor server machine through ssh, using the same ssh-keys that you use to connect to the NITOS server machine.

Nitlab 1.0 documentation »

previous | index

© Copyright 2014, Simos Iordanidis. Created using Sphinx 1.1.3.

Μελλοντικά ζητήματα

- Το εγχειρίδιο μπορεί να εμπλουτιστεί και με άλλες κατηγορίες, όπως **LTE Experimentation** και **Software Defined Radio**.
- Αγγλική παρουσίαση του εγχειριδίου.

Τι αποκόμισα...

- Βασικές γνώσεις για την χρήση του Nitos Testbed και τον πειραματισμό με τις διάφορες τεχνολογίες.
- Εκμάθηση εργαλείων(Sphinx,Github).
- Εκμάθηση βασικών στοιχείων HTML/CSS

Πηγές

- <http://nitlab.inf.uth.gr/NITlab/>
- <http://mytestbed.net/>
- <http://sphinx-doc.org/>
- <https://github.com/>

Ερωτήσεις

